



NOTE:

WHERE DRAIN LINE CROSSES PREVIOUSLY INSTALLED SANITARY SEWER, WATER OR GAS MAIN, ETC. TRENCH SHALL BE EXCAVATED DOWN TO THE PREVIOUSLY LAID CONDUIT AND BACKFILLED WITH COMPACTED #2 CRUSHER RUN STONE TO INSURE ADEQUATE SUPPORT.

DRAIN LINE BEDDING DETAIL

NOT TO SCALE

4/1/98

REVISED